

## Codes pour téléviseurs

Admiral.....	018,090,125	JVC.....	057,058,059,060,186,234
A-Mark.....	120,224,225	Kawasho.....	061
Aiwa.....	090,251	Kenwood.....	006,251
Akai.....	000,032,070,149,172	Kloss.....	022,110
Amstrad.....	033	KMC.....	224,225
Anam.....	005,009,021,041,120,121	KTV.....	026,039,041,172,224,225
Anam National.....	211	Lloytron.....	224
AOC.....	005,006,019,020,120,140,163,173	Lodgenet.....	018
Archer.....	120	Logik.....	018
ASA.....	047	Luxman.....	023,213
Audio Dynamics.....	234	LXI.....	003,010,066,090,117,125,129,131
Audiovox.....	120	.....	134,172,173,194,223,251,254
Bell & Howell.....	018	Magnavox.....	000,006,008,010,017,020,025,027
Broksonic.....	005,144,172,173,174,219,226	.....	028,066,067,068,110,144,151,154,163,164
Candle.....	006,022,023,025,163,213	.....	167,172,173,175,192,194,218,224,225,231,251
Capehart.....	019	Majestic.....	018
Centurion.....	192,194	Marantz.....	006,010,066,068,088,149,163,172,234
Citizen.....	006,016, 018,022,023,024,025,026	Marta.....	223
.....	144,163,202,213,224	Matsui.....	032,109
Concerto.....	005,023,213	Memorex.....	018,032,090,223,232,251
Contec.....	041,091,185,227	MGA.....	004,005,006,023,034,071,072,149
Coronado.....	224,225	.....	163,172,187,192,194
Craig.....	021,041	Mitsubishi.....	004,005,023,034,070,071,072,122
Crown.....	026	.....	123,149,172,173,187,192,194
Curtis Mathes.....	006,016,018,026,059,125,163	MTC.....	005,006,016,023,031,163,202,213
.....	172,192,194,202,224,231	NAD.....	002,117
CXC.....	041	NEC.....	005,006,007,023,028,090,144,163
Daewoo.....	005,024,026,029, 030,031,032,130	.....	172,173,191,192,194,213
.....	172,214,215,224,233,252	National.....	011,151,190,195,196,211
Daytron.....	026,192,194,224	Nikkai.....	113,118
DBX.....	234	Onwa.....	041
Dimensia.....	125	Optimus.....	232
Dumont.....	047	Optonica.....	129
Electrohome.....	026,149,224	Orion.....	219,226
Emerson.....	017,023,026,028,033,034,035,037,038	Osume.....	091
.....	039,041,122,141,143,144,172,176,187,203	Panasonic.....	008,009,010,011,012,066,151,195
.....	204,205,219,222,223,224,225,226,227,251,253	.....	196,211, 231, 232
Envision.....	163	Philco.....	005,006,025,067,068,110,151,163
Fisher.....	042,090,099,216,217	.....	172,218,224,225,251
Fujitsu.....	034,187	Philips.....	005,010,025,027,066,068,088,146
Funai.....	034,041,187,251	.....	151,163,164,218,220,223,225,251
Futuretech.....	041	Pioneer.....	002,008,048,051,076
GE.....	003,008,009,023,043,044,125,130	Portland.....	005,026,172,224,225
.....	134,147,172,195,206,207,211,228,231	Proscan.....	125,147,172
Goldstar.....	005,023,026,045,046,088,172,173	Proton.....	006,013,019,023,026,172,224
.....	194,213,223,224,225,230,234,254	Pulsar.....	001
Grundig.....	047	Quasar.....	008,009,195,211,231,232
Hallmark.....	023	Radio Shack.....	026,041,112,141,173,194,224,229
Harmon Kardon.....	234	.....	230,232
Hinari.....	034,187	RCA.....	003,005,008,014,048,078,079,080
Hitachi.....	018,023,026,048,049,050,051,052	.....	082,084,085,086,087,125,130,134
.....	053,054,055,116,126,142,172,185	.....	147,172,210,231,251
.....	213,224,225,231,251	Realistic.....	035,041,090,141,194,222,223,
Infinity.....	010,066,151	.....	224,229,251
JBL.....	010,066,151	SAA.....	145
JCPenny.....	003,005,006,014,016,026,043,044	Saba.....	051,116,142
.....	096,125,134,163,172,194,206,207	Saisho.....	032,033,109
.....	223,224,231,232,234	Sampo.....	006,019,163,192,194
Jensen.....	056	Samsung.....	005,006,016,023,026,032,088,112

..... 163,172,173,192,194,202,213,221  
 ..... 224,225,229,233  
 Sansui ..... 219  
 Sanyo ..... 042,089,090,091,092,109,194,216,217  
 Scott ..... 026,034,037,041,093,173,187,192  
 ..... 194,224,233  
 Sears ..... 003,023,034,042,090,096,098,099  
 ..... 101,102,104,117,125,131,134,151  
 ..... 187,194,202,216,217,223,224,225  
 Sharp ..... 026,091,129,141,200,224,225  
 Signature ..... 018,251  
 Sony ..... 000,109,119,122  
 Soundesign ..... 023,025,041,172,251  
 Spectricon ..... 120  
 SSS ..... 005,041  
 Supra ..... 022,023  
 Sylvania ..... 006,010,025,066,068,110,112,151  
 ..... 163,172,173,192,194,229,251  
 Symphonic ..... 132,179,251  
 Tandy ..... 112,113,129,251  
 Tatung ..... 009,211  
 Teac ..... 251  
 Technics ..... 008,032  
 Techwood ..... 023,213

Teknika ..... 004,005,016,018,022,023,024,025  
 ..... 026,034,041,072,114,149,151,187  
 ..... 202,213,223,224,225,251  
 Telerent ..... 018,224  
 Teletech ..... 032  
 Thomson ..... 051,116,142  
 TMK ..... 023,172,213  
 Toshiba ..... 016,017,047,090,096,117,118,131  
 ..... 180,201,202,216,233  
 Totevision ..... 026,223,224  
 Universal ..... 043,044,206,207  
 Vector Research ..... 006,234  
 Victor ..... 057  
 Video Concepts ..... 070,234,251  
 Vidtech ..... 005,023,172,173  
 Viking ..... 022  
 Wards ..... 005,006,018,023,034,043,044,067  
 ..... 068,119,125,141,151,163,172,173  
 ..... 187,192,194,206,207,224,251  
 Westinghouse ..... 090  
 Yamaha ..... 005,006,234,251  
 Yorx ..... 192,194  
 Zenith ..... 001,018,178,219,223,251  
 Zonda ..... 120