

VCR Codes

Aiwa	088,202	Minolta.....	094
Akai	008,013,014,015,016,018,019,020	Mitsubishi.....	062,067,068,069,070,071,109,124
.....	145,157,198,210	125,140,183,211
Alba	046	MTC.....	080,088,214
Amstrad	088,214	Multitech.....	088,089,091,214
ASA.....	065	NAD.....	073,153
Audio Dynamics	030,093,210	National.....	184
Broksonic.....	008,059,148	NEC.....	030,031,032,062,081,092,093,100
Bush.....	089	102,127,128,160,210
Cannon.....	054	Nordmende.....	210
Canon.....	022,042,056,080,092,093	Optonica.....	072,085
Capehart.....	043,046	Orion.....	006
Citizen	056,091,092,093	Panasonic	021,022,023,024,026,054,098,114
Craig	044,082,091	129,184
Curtis Mathes.....	054,092,105,184	Pentax.....	037,092,094
Daewoo.....	034,046,093,150,204,206	Philco	054,111,184
Daytron.....	046,206	Philips	054,065,085,154,155,184
DBX	030,093,210	Pioneer	062,073,074,075,076,093
Dimensia.....	105	Portland	046,093,206
Dual	210	Proscan.....	105
Dumont.....	049	Pulsar.....	033
Dynatch	088,214	Quartz.....	081
Electrohome.....	109	Quasar	054,078,184
Emerson.....	005,006,008,009,010,011,012,059	Radio Shack	081,082,084,085,109,184,188,214
.....	068,088,090,109,132,190,192,193	RCA	025,026,027,028,037,091,105,146,147,162
.....	198,204,211,212,213,214	Realistic.....	049,054,080,081,082,084,085,088
Ferguson	210	184,188,214
Finlandia.....	049	Saba.....	210
Finlux.....	049,065,088,214	Saisho.....	006,212
Fisher.....	048,049,081,082,084	Salora	067,081,183
Funai.....	088,214	Samsung.....	015,034,079,080,091,186,204
General Electric	025,050,051,052,053,054,091,105	Sansui.....	032,062,093,210
.....	133,184	Sanyo.....	044,049,081,082,083
Go Video	057,058,164,186	SBR.....	065
Goldstar	030,033,056,092,102	Schaub Lorenz.....	210
Goodmans.....	085,089	Schneider.....	089
Graetz	210	Scott	008,034,059,090,183,204,212,213
Granada	049,081	Sears	048,049,081,082,084,094
Grundig.....	065	Sentra	046
Harman/Kardon	030,069	Sharp	085,109,130,188
Hinari.....	089	Sony	000,001,002,003
Hitachi	036,037,038,040,041,088,094,095	Sylvania.....	054,067,088,111,183,184
.....	121,210,214	Symphonic	214
ITT.....	018,210	Tandy	081,082,084,085,088,109
Instant Replay.....	184	Tashiko.....	088
JC Penney.....	030,052,054,080,081,091,093,094,184	Tatung	086,210
JCL	184	Teac.....	088,210,214
Jensen	060,210	Teknika	054,087,088,184,214
JVC.....	061,062,063,064,081,092,093,122,123,210	Telefunken	210
Kenwood	062,081,092,093,210	Thomson	210
Lloyd	088,214	Thorn.....	210
Logik	089	TMK.....	006
Luxor	018	Toshiba.....	034,035,067,084,090,183,204,210
Magnavox	027,034,054,065,088,111,130,134	Totevision.....	080,091
.....	136,137,138,139,141,142,143,158,159,184	Unitech.....	080
Marantz.....	030,054,065,081,085,092,093,102,184	Vector Research	030,092,093,183
MEI.....	054,184	Video Concepts	068,092,093
Memorex	033,049,054,066,081,082,085,088	Videosonic	091
.....	184,214	Wards	027,054,080,082,085,088,089,090,091
MGA.....	067,068,109,183,211	109,156,161,184,188,214

Yamaha..... 030,081,092,093,210

Zenith.....033, 062