

## Codes pour magnétoscopes

Aiwa .....	088,202	Minolta.....	094
Akai .....	008,013,014,015,016,018,019,020	Mitsubishi.....	062,067,068,069,070,071,109,124
.....	145,157,198,210	.....	125,140,183,211
Alba .....	046	MTC.....	080,088,214
Amstrad .....	088,214	Multitech.....	088,089,091,214
ASA.....	065	NAD.....	073,153
Audio Dynamics .....	030,093,210	National.....	184
Broksonic.....	008,059,148	NEC.....	030,031,032,062,081,092,093,100
Bush.....	089	.....	102,127,128,160,210
Cannon.....	054	Nordmende.....	210
Canon.....	022,042,056,080,092,093	Optonica.....	072,085
Capehart.....	043,046	Orion.....	006
Citizen .....	056,091,092,093	Panasonic .....	021,022,023,024,026,054,098,114
Craig .....	044,082,091	.....	129,184
Curtis Mathes.....	054,092,105,184	Pentax.....	037,092,094
Daewoo.....	034,046,093,150,204,206	Philco .....	054,111,184
Daytron.....	046,206	Philips .....	054,065,085,154,155,184
DBX .....	030,093,210	Pioneer .....	062,073,074,075,076,093
Dimensia.....	105	Portland .....	046,093,206
Dual .....	210	Proscan.....	105
Dumont.....	049	Pulsar.....	033
Dynatch .....	088,214	Quartz.....	081
Electrohome.....	109	Quasar .....	054,078,184
Emerson.....	005,006,008,009,010,011,012,059	Radio Shack .....	081,082,084,085,109,184,188,214
.....	068,088,090,109,132,190,192,193	RCA .....	025,026,027,028,037,091,105,146,147,162
.....	198,204,211,212,213,214	Realistic.....	049,054,080,081,082,084,085,088
Ferguson .....	210	.....	184,188,214
Finlandia.....	049	Saba.....	210
Finlux.....	049,065,088,214	Saisho.....	006,212
Fisher.....	048,049,081,082,084	Salora .....	067,081,183
Funai.....	088,214	Samsung.....	015,034,079,080,091,186,204
General Electric .....	025,050,051,052,053,054,091,105	Sansui.....	032,062,093,210
.....	133,184	Sanyo.....	044,049,081,082,083
Go Video .....	057,058,164,186	SBR.....	065
Goldstar .....	030,033,056,092,102	Schaub Lorenz.....	210
Goodmans.....	085,089	Schneider.....	089
Graetz .....	210	Scott .....	008,034,059,090,183,204,212,213
Granada .....	049,081	Sears .....	048,049,081,082,084,094
Grundig.....	065	Sentra .....	046
Harman/Kardon .....	030,069	Sharp .....	085,109,130,188
Hinari.....	089	Sony .....	000,001,002,003
Hitachi .....	036,037,038,040,041,088,094,095	Sylvania.....	054,067,088,111,183,184
.....	121,210,214	Symphonic .....	214
ITT.....	018,210	Tandy .....	081,082,084,085,088,109
Instant Replay.....	184	Tashiko.....	088
JC Penney.....	030,052,054,080,081,091,093,094,184	Tatung .....	086,210
JCL .....	184	Teac.....	088,210,214
Jensen .....	060,210	Teknika .....	054,087,088,184,214
JVC.....	061,062,063,064,081,092,093,122,123,210	Telefunken .....	210
Kenwood .....	062,081,092,093,210	Thomson .....	210
Lloyd .....	088,214	Thorn.....	210
Logik .....	089	TMK.....	006
Luxor .....	018	Toshiba.....	034,035,067,084,090,183,204,210
Magnavox .....	027,034,054,065,088,111,130,134	Totevision.....	080,091
.....	136,137,138,139,141,142,143,158,159,184	Unitech.....	080
Marantz.....	030,054,065,081,085,092,093,102,184	Vector Research .....	030,092,093,183
MEI.....	054,184	Video Concepts .....	068,092,093
Memorex .....	033,049,054,066,081,082,085,088	Videosonic .....	091
.....	184,214	Wards .....	027,054,080,082,085,088,089,090,091
MGA.....	067,068,109,183,211	.....	109,156,161,184,188,214

Yamaha..... 030,081,092,093,210

Zenith.....033, 062